


Economy class printer **JetLT-A3**



SWITCH ON




Connect the printer to a 220V mains

Turn on the printer platform

Turn on the printer

instal to Computer

SWITCH OFF



Turn off the printer

Turn off the printer platform


Removing and installing the platform



Monitor the ink level regularly

Max




Min



Printing:
Starting position,
start printing from computer




Printer settings on the computer



off

Cleaning



Test

